

**Attention**

1. Battery voltage must be within 2 - 5V range.
2. Maximum input voltage is 50Vpk for 1X probe.
3. Do not attempt to measure live power directly.


**Panel & Connectors**

Fig. 1



Fig. 2




Fig. 3




Fig. 4

**Button Functions**

Button functions are mode dependent. Please see their function under different modes below.

Under any mode:

[ADJ] hold - power off, [LEVEL] hold - backlight ON/OFF

**1. Oscilloscope Mode**

RUNNING	
Button Name	Function
[VPOS]	Select vertical position
[HPOS]	Select horizontal position
[SEC/DIV]	Select timebase
[MODE]	Select trigger mode
[SLOPE]	Select trigger slope
[LEVEL]	Select trigger level
[HOLD]	Enter HOLD
[ADJ] rotating	Adjust parameter selected
[ADJ] press	Enter MENU
[VPOS] hold	Align vertical position
Sen. selector 1	Change sensitivity
Sen. selector 2	Change sensitivity
Couple selector	Change couple

**2. Frequency Meter Mode**

Button Name	Function
[ADJ] press	Enter MENU
Sen. selector 1	Change sensitivity
Sen. selector 2	Change sensitivity
Couple selector	Change couple

**3. FFT Mode**

Button Name	Function
[ADJ] press	Enter MENU
[HPOS]	Select FFT size
[SEC/DIV]	Select FFT sampling rate
[ADJ] rotating	Adjust parameter selected

**Basic Operations****1. Connection**

Connect probe to the BNC connector marked "INPUT" (Fig 4). Connect USB cable if the unit is powered by USB (Fig. 2).

**2. Power on & off**

Power ON: Press [ADJ] dial once. System will first enter Bootloader, stay for about 2 seconds, and then enter running state.

Power OFF: Hold [ADJ] dial for about 3 seconds.

**3. Set parameters**

Oscilloscope parameters can be grouped by three main categories: vertical, horizontal, and trigger.

**1) Vertical --- including SENSITIVITY, POSITION, and COUPLE.**

To set SENSITIVITY use the upper two slide switches. Setting is displayed on screen as "volt/div".

To change vertical POSITION press [VPOS] button and then turn [ADJ] dial.

To change COUPLE use the lower slide switch

**2) Horizontal --- including TIMEBASE and POSITION**

To set TIMEBASE press [Sec/Div] button and then turn [ADJ] dial.

To change horizontal POSITION press [HPOS] button and then turn [ADJ]. Setting is displayed as "Second/div" on screen.

**3) Trigger --- including trigger MODE, SLOPE, and LEVEL**

To set trigger MODE press [MODE] button and then turn [ADJ] dial

To set trigger SLOPE press [SLOPE] button and then turn [ADJ] dial

To change trigger LEVEL press [LEVEL] button and then turn [ADJ] dial

**What Trigger Mode Means and How to Use It**

The trigger can work under automatic (AUTO), normal (NORM), or single (SING) mode. Under AUTO mode the scope will perform capture and display results no matter there is triggering or not. Under NORM mode the scope performs capture and updates display only when triggering happens. The SING mode is similar to NORM mode. The only difference is under SING mode the scope will enter HOLD state automatically after a capture and will stay until manual release.

When trigger mode is set to NORM or SING you may find no screen updates. This is because there is no trig happening. In this case you may like first switch to AUTO mode to make sure signal and trigger level are in proper range and then switch back to NORM or SING.

**Menu Operations****1. Press [ADJ] to have menu displayed.****2. Turn [ADJ] to select function and press [ADJ] to execute.****Menu Functions**

No.	Menu Item	Function Descriptions
0	OSCILLOSCOPE	Enter oscilloscope mode
1	FREQ METER	Enter frequency meter mode
2	FFT	Enter FFT mode
3	SAVE WAVEFORM	Save waveform. The last waveform captured before enter menu is saved to EEPROM. (This function is only available under oscilloscope mode)
4	RECALL WAVEFORM	Recall saved waveform from EEPROM and display it in HOLD state. (This function is only available under oscilloscope mode)
5	SEND SCREEN	Send screen as bitmap file via serial port. The screen right before entering menu will be sent. XModem protocol is used for the transfer. Refer to documents at <a href="http://www.jyotech.com">www.jyotech.com</a> .
6	SEND WAVE DATA	Send waveform data as CSV file via serial port. The displayed waveform right before entering menu will be sent. XModem protocol is used for the transfer.
7	CHANGE REC. LEN	Select record length by turning [ADJ]. Record length can be set to 256, 512, or 1024.
8	CHANGE TRIG POS	Select trigger position by turning [ADJ]. Trigger position can be set to 1% - 100% of capture buffer.
9	TEST SIGNAL	Set the frequency and amplitude of test signal. Use [ADJ] to change frequency. Press [LEVEL] to select amplitude.
10	RESTORE DEFAULT	Reset parameters to factory defaults. See the table in next page for affected parameters.
11	REBOOT	Reboot device (usually to enter bootloader for firmware upgrading).
12	EXIT	Exit menu and return to previous state.

## Advanced Operations

### 10X Probe Calibration

Due to input capacitance 10X probe must be calibrated for correct amplitude display. The calibration can be performed by use of the built-in test signal generator of 068.

- 1) Enter menu. Set test signal to 1KHz and 5V respectively.
- 2) Set the switch on probe handle to "10X" position.
- 3) Set timebase to 0.2ms and sensitivity to 0.2V (see Fig. 6).
- 4) Place probe tip onto the central conductor of test signal connector (Fig. 5). Adjust trigger level if display is not stable.
- 5) Adjust the cap trimmer at probe connector with small screw driver (see Fig. 5) so as sharp rectangle waveform is displayed (middle screen of Fig. 6).




Fig. 5




Fig. 6

Not enough

Good

Too much

### Vertical Position Alignment

In case of that there is a mismatch between 0V trace and the vertical position indicator please follow the steps below to eliminate it.

- 1) Set couple switch to GND position.
- 2) Hold [VPOS] for about 3 seconds. You should see the 0V trace aligned to the indicator.

### USB Connection

In order to use USB function the host which DSO 068 is to communicate with is required to install driver supporting the USB-Uart bridge CP2102. Please use the following link to download driver and install it (referring to documents accompanying).

[www.silabs.com/products/mcu/pages/usbtouartbridgevcpdrivers.aspx](http://www.silabs.com/products/mcu/pages/usbtouartbridgevcpdrivers.aspx)

### Serial Port Parameters

For the main firmware serial port parameters are fixed to 115200 bps and 8-N-1.

For the bootloader serial port parameters are fixed to 9600 bps and 8-N-1.

### Screen Image & Waveform Data Upload

Use XModem supporting software (such as Tera Term) for uploading. Name screen image to "bmp" file. Name waveform data to "csv" file. First start sending from menu and then start receiving at host. Note that the screen or waveform displayed right before entering menu will be sent.

### Boot Process and Indication

At powering-up or reset system first enters bootloader (bootloader is installed before shipment). LED D1 will flash once. If jumper JP7 is closed buzzer will beep once accordingly. System will stay in bootloader for about 2 seconds detecting firmware upgrading request from host. If no request received it will enter the main firmware.

Once in the main firmware JYE Tech logo will be displayed together with firmware versions. LED D1 will flash twice. If jumper JP7 is closed buzzer will beep twice accordingly. System then enters working state.

The activities of LED and buzzer serve as indication of correct booting.

### Forced Default Recovery

Normally factory default can be recovered by menu. It can also be done by connecting PF6 (at J7) to ground and performing reset (press SW12 for example). Remember to disconnect PF6 from ground after recovery is done.

#### Factory Default

Timebase	1ms/DIV
Vertical Pos	0
Horizon. Pos	80
Trigger Mode	AUTO
Trigger Slope	Falling
Trigger Pos	50%
Record Len.	256 points
Test Sig. Freq.	1000Hz
Test Sig. Amp.	5V

## Firmware Upgrading

DSO 068 contains two AVR microcontrollers from Atmel: ATmega64 (U4) and ATmega48 (U5). Their function and performance can be changed by changing firmware.

Note that the firmware of U4 can be changed by programmer or bootloader. Firmware of U5 can only be changed by programmer.

### By Programmer

The program ports for U4 and U5 are J4 and J5 respectively. Their pinout is compatible to STK200 and is shown in Fig. 7. It is important to pick up a programmer with matching programming header. JYE Tech offers compatible programmer (PN: 07302).

Follow instructions of selected programmer and host application to perform firmware upgrading.

### By Bootloader

DSO 068 has bootloader pre-installed which can work with a PC application via serial connection to perform firmware upgrading. The PC application is called AVRUBD. It can be downloaded at <http://www.jyetechnology.com/Support/avrubd.rar>

For how to use bootloader please refer to the article "How to Upgrade Firmware by Bootloader" (<http://www.jyetechnology.com/Support/HowToUpgradeFirmwareByBootloader.pdf>).

DSO 068 can enter bootloader by one of three methods: 1) powering-up; 2) executing menu item REBOOT; 3) pressing switch SW12.

### Fuse Bits Setting

It is important to have correct fuse bit setting for DSO 068 to run normally. The factory fuse setting for U4 and U5 are listed in tables at right. Please do not change them unless you know what you are doing.

#### J4 and J5 pinout




Fig. 7

U4(ATmega64) Fuse Bits	
Ext. byte	0xFF
High byte	0xC2
Low byte	0x2E

U5(ATmega48) Fuse Bits	
Ext. byte	0xFF
High byte	0xD6
Low byte	0xE2 ("F" PCB) 0xE0 ("H" PCB)

## Use Battery

DSO 068 can be powered by battery. Typically 3.7V/1200mAh Li-ion battery is used. When fully charged it can run the device about 4 hours with backlight on.

The assembly BOB2 (JYE118) is battery/USB power switch and battery charger. It charges battery once USB is connected. The charging process is fully automatic and terminates itself when battery is full. The charge current can be programmed by R32. Please refer to datasheet of JYE118 for details.

Short JP5 if external battery is to be used. **Note:** Internal battery must be removed in this case.

## Equivalent-Time Sampling (ETS)

When timebase is set to 2us or faster capture will automatically use Equivalent-Time Sampling method. This method can display more details of signal. But there are two conditions for it to work:

- 1) Signal must be periodic.
- 2) Trig must happen.

As a result in ETS you may see no screen activity if any of these conditions are not met. In this case try adjusting trigger level to make trig happen.

Note that trig point has no meaning in ETS.

## Data Interface

The data interface of DSO 068 is a serial interface of Uart (TTL level) or USB. It has two main functions:

- 1) Working with jyeLab as USB Scope.
- 2) High resolution (10 bits) Data Logger.

Details of the data interface are separately documented.

## Specifications

Max ETS sampling rate	20MSa/s
Max realtime sample rate	2MSa/s
Analog bandwidth	0 -- 3MHz
Sensitivity range	10mV/div - 5V/div
Max input voltage	50Vpk (1X probe), 400Vpk (10X probe)
Input impedance	1M ohm/20pF
Resolution	8 bits
Record length	256,512,1024 points (variable)
Timebase range	10m(minute)/Div -- 0.5us/Div
Trigger modes	Auto, Normal, and Single
Trigger position range	0% -- 100%
Frequency meter range	5MHz
F. meter sensitivity	0.2Vpp @ 5MHz
Power supply	3.7V Li-ion batter / USB
Current consumption	~300mA (with LCD backlight ON)
Dimension	140 x 70 x 30mm
Weight	~0.18KG (without battery and probe)



# DSO 068 Oscilloscope DIY Kit

## Assembly Guide


Rev F01

### Step 1 Assembly Main Board

1. Complete the steps in "Get Ready" and understand soldering requirements.
2. Install parts by the order of part list. Start from the back side of main board.
3. Pay special attention to part polarity at soldering. Refer to photos to the right.
4. For BOB boards and LCD soldering refer to photos at bottom for details.
5. After all back side parts are finished perform powering-up test as explained at the reverse page. Continue rest installation if test result is good.

**TIP:** Resistor values are easily mis-read. Ohm meter check is strongly suggested.

**TIP:** C3 and R32 are not required.



**TIP:** Do not install J4 & J5. They can be inserted into programmer header at programming.

#### Tools

- ① Iron (20W)
- ② Solder wire
- ③ Multimeter
- ④ Screw driver
- ⑤ Flush cutter
- ⑥ Tweezers


#### Get Ready

- ① Check part values & quantities against part list
- ② Meter and identify resistor values by ohm meter
- ③ Understand all part polarities and orientations


#### Identify Polarity & Orientation



JYE116 (BOB4)  
(Pin 1 indicated by arrow)




Diode




JYE117 (BOB3)




LED




JYE118 (BOB2)



Electrolytic cap.



JYE119 (BOB1)




Transistor



JYE120 (BOB5)


#### Front Side



**Important! Unused leads under LCD must be cut flush to avoid short to LCD module!**

#### BOB Boards Installation

Pin 1 location indicated by arrow (square pad)




#### BOBs and Jumpers

Keep JP1 open if BOB2 is installed. Otherwise short it.  
Keep JP2 open if BOB3 is installed. Otherwise short it.  
More at the reverse page


#### BOB Board Installation




A. Use the small acrylic tool provided.




B. Apply solder to one pin.




C. Apply solder to the corresponding pin on main PCB.



D. Put BOB to place and align pads.




E. Maintain BOB upright and fix it by melting the solder.



F. Finish the rest pins.

#### Soldering Skills and Requirements

- ① Put leads through mounting from installation side of PCB. Ensure they evenly touch PCB (picture below).
- ② Solder at the other side of PCB. Solder should fully fill and cover soldering pads. Avoid bridges with neighboring pads.
- ③ Cut unused leads flush with cutter.



**Note:** Please install by the order given in the Part List below.


#### Part List

Category	Seq.	Type/Spec	Qty	Designator/Location
Main PCB	1	101-06802	1	
Resistor	2	510K $\Omega$ , 5%, 1/8W	2	R1, R27
	3	200K $\Omega$ , 1%, 1/8W	1	R3
	4	2M $\Omega$ , 1%, 1/8W	2	R2, R4
	5	20K $\Omega$ , 1%, 1/8W	1	R5
	6	300 $\Omega$ , 1%, 1/8W	2	R6, R23
	7	180 $\Omega$ , 1%, 1/8W	1	R7
	8	120 $\Omega$ , 1%, 1/8W	2	R8, R12
	9	3.3K $\Omega$ , 1%, 1/8W	2	R10, R22
	10	470 $\Omega$ , 1%, 1/8W	3	R11, R31, R33
	11	0 $\Omega$ , 5%, 1/8W	1	R13
	12	10K $\Omega$ , 1%, 1/8W	4	R9, R21, R20, R30
	13	1K $\Omega$ , 5%, 1/8W	5	R24, R25, R26, R28, R29
	14	10M $\Omega$ , 5%, 1/8W	1	R40
Diode	15	1N4148, DO-35	2	D2, D3
Inductor	16	100uH, $\phi$ 2.5 X 6mm	3	L1, L4, L5
Crystal	17	20MHz, HCM-49	1	Y1
Connector	18	USB socket, MiNi-B type	1	J1
Switch	19	Tact, 6 X 6 X 5mm	1	SW12
Capacitor	20	300pF, ceramic disk	2	C2, C23
	21	3pF, ceramic disk	1	C4
	22	1pF, ceramic disk	1	C6
	23	120pF, ceramic disk	2	C7, C13
	24	0.1uF, ceramic disk	12	C9, C10, C11, C12, C14, C15, C16, C18, C20, C24, C25, C26
	25	15pF, ceramic disk	2	C21, C22
	26	0.1uF/100V, CBB	1	C1
Buzzer	27	5V, passive, $\phi$ 9 X 5.5mm	1	BP1
Diode	28	LED, $\phi$ 3mm, red	1	D1
Connector	29	2pins, 2.54mm	2	J6, J10
Transistor	30	8550, TO-92 (E-B-C)	2	Q1, Q2
Electro. Capacitor	31	10uF, 16V, $\phi$ 4 X 5mm	1	C19
	32	100uF, 16V, $\phi$ 6 X 7mm	5	C17, C27, C28, C29, C30
Connector	33	DC005, $\phi$ 2.1mm core	1	J2
BOB Board	34	JYE116, step-up converter	1	BOB4
	35	JYE120, neg. P.S. convertor	1	BOB5
	36	JYE117, On/Off switch	1	BOB3 (optional)
	37	JYE118, battery charger	1	BOB2 (optional)
	38	JYE119, UART-UART conv.	1	BOB1 (optional)
<b>Now perform power-up test. See steps at the reverse page. Continue following assembly after test.</b>				
Switch	39	Slide switch, SS-23D06	3	SW1, SW2, SW3
Switch	40	Rotary Enc., EC11, 10mm	1	SW4
Pin Strip	41	SIP, 2mm, 20X1	1	ASSY1
Pin Strip	42	SIP, 2mm, 2X1	2	ASSY2, ASSY3
LCD	43	128X64 graphic, 12864-16	1	LCD1
Pin strip	44	DIP, 2.54mm, 5X2	2	J4, J5 (Do not install)
Enclosure	45	Top(1), bottom(1), stand(1) switch caps(3), dial cap(1)	1 set	
Switch	46	7-key silicone button pad	1	
Connector	47	BNC, BNC-KY	2	
Wire	48	2-core hood-up wire, 10cm	1	
Screw	49	2.3*8mm, self tapping	4	
Acrylic	50	Tool for holding BOB	1	






## Step 2

## Power Up the First Time




## Step 3

## Adjust Compensation Capacitors







Compensation capacitors can be adjusted using the built-in signal generator. Follow steps below:

1. Connect test signal output to scope input (see photo below) and set SW1 to DC.
2. Power up. Set test signal to 10KHz and 5V. Set scope timebase to 20us.
3. Set SW & SW3 to 1V & X2 respectively. Adjust trigger level to make display stable if necessary. Change C8 to obtain waveform as the middle of photos left.
4. Keep signal frequency unchanged and set amplitude to 1V. Set SW2 & SW3 to 0.1V and X5 respectively. Make display stable. Change C5 to obtain waveform as the middle of photos left.
5. Remove connection between test signal output and scope input. Adjustment is done.



## Step 4

## Install Batter & Enclosure



Tech Support: [www.jyetechnology.com/forum](http://www.jyetechnology.com/forum)

## Check Mode and Its Usage

### What is "Check Mode"

Check Mode is to assist connection checking for most MCU pins. Once in Check Mode MCUs will generate high and low levels at those pins. These levels can be easily checked with a volt meter and consequently find out pin connections. This is particularly useful for checking out suspicious SMD solderings.

### How to Enter "Check Mode"

Close JP6 and power up the system. It will enter "Check Mode". You should see LED flashes at about 3 second cycle.

Remember restore JP6 to open after checking.

### Use of "Check Mode"

We want to check the connection between U3 pin12 and U4 pin17, for example. First enter Check Mode as stated earlier. Measure voltage at U3 pin12 with a volt meter. If voltage change between 0V and 5V is observed the connection is good. Otherwise is bad.

### "Check Mode" Related Pins

Not all pins have the Check Mode function. The pins that do are listed as following:

U4: PB[7:5, 3:0], PC[7:0], PD[7, 5, 3, 1, 0], PE[7:3], PF[7:0], PG[4:0]

U5: PB[5:1], PC[3:0], PD[7, 6, 4:1]

## Major Jumpers Explained

**JP1:** This by-pass of charger BOB2. If battery is not used (as result, no BOB2) keep JP1 closed.

**JP2:** This is by-pass of switch BOB3. If BOBs is not used JP2 should be closed. In order to focus on the main circuit we temporarily close JP2 at power-up test even BOBs is installed. It is kept open after test.

**JP3:** This is by-pass of step-up converter BOB4. Usually JP3 is kept open.

**JP4:** This is the connecting point of power supply and the rest circuits. For the safety of the rest circuit only close JP4 after power supply is tested good.

## Troubleshooting

**Notes:** 1. All voltages are measured with volt meter's (-) pole at reference point (indicated in photo below) and (+) pole at points of measurement.  
2. Voltages with " \* " are measured when SW1 (couple) is placed at GND position.

